


Explosive View and Parts list

Issue date: 2013.06.28
Version no.: V2



No.	Figure number	Description	Qty.	No.	Figure number	Description	Qty.
1	03.04.05.691	Hex Bolt M8*20	1	53	03.04.03.086-01	Trigger	1
2	03.04.29.186	Cylinder pin	1	54	03.04.05.191	Pin 3*1.5	2
3	03.04.01.063	O-ring 10*2	1	55	03.04.16.113	Iron skateboard frame	1
4	03.04.21.507-01	Exhaust Deflector	1	56	03.04.16.114	Plastic skateboard frame	1
5	03.04.25.136	Exhaust seal	1	57	03.04.36.271	Spring	1
6	03.04.19.152	Cylinder cover bumper	1	58	03.04.16.115	Safety yoke	1
7	03.04.05.047	Hex bolt M6*25	4	59	03.04.01.170	O-ring 46*2	1
8	03.04.16.112	Gun body frame	2	60	03.04.01.040	O-ring 4*1.5	1
9	03.04.28.087-02	Cylinder cover	1	61	03.04.08.177	Nose	1
10	03.04.19.153	Cylinder cover sealing gasket	1	62	03.04.05.047	Hex bolt M6*25	4
11	03.04.19.154	Spring washer	1	63	03.04.29.187	Bushing	4
12	03.04.32.140	Spring holder	1	64	03.04.31.122	Cover plate pin	1
13	03.04.36.270	Spring	1	65	03.04.40.052	Fixed rubber plug	1
14	03.04.06.125	Lining ring	1	66	03.04.40.344	Gun head protective film	1
15	03.04.01.181	O-ring 51*2.65	2	67	03.04.10.053	Trigger piece	1
16	03.04.01.160	O-ring 42.5*2.5	1	68	03.04.36.272	Spring	1
17	03.04.20.040	On-off valve	1	69	03.04.36.273	Spring	1
18	03.04.19.155	Cylinder sealing	1	70	03.04.17.121	Check nail claw	1
19	03.04.39.12.040	Piston driver	1	71	03.04.13.172	Cover plate	1
20	03.04.01.145	O-ring 37.5*3.55	1	72	03.04.05.190	Pin 3*1.2	1
21	03.04.27.127	Cylinder	1	73	03.04.31.118	Check nail pin	1
22	03.04.01.174	O-ring 48.7*2.65	1	74	03.04.24.029	Send nail claw spring	1
23	03.04.19.156	Sealing gasket	1	75	03.04.33.014	Send nail claw	1
24	03.04.19.157	Shaft washer	1	76	03.04.31.119	Send nail claw pin	1
25	03.04.01.266	O-ring 74.4*3.1	1	77	03.04.01.061	O-ring 9.9*2.4	1
26	03.04.06.126	Bumper	1	78	03.04.40.345	Send nail piston	1
27	03.04.26.207-02	Gun body	1	79	03.04.01.099	O-ring 20.4*2.4	1
28	05.04.33.678	model label	1	80	03.04.22.033	Spring	1
29	05.04.08.316	Warning label	1	81	03.04.22.034	Spring	1
30	03.04.29.096	Rubber grip	1	82	03.04.31.120	Pin	1
31				83	03.04.06.127	Buffer channel	1
32	03.05.04.052	Spring pin 3*28	4	84	03.04.32.141	Spring holder	1
33	03.04.02.054	O-ring 34.5*2.65	1	85	03.05.03.031	Ring	1
34	03.04.11.084	Air inlet end cap-01	1	86	03.04.40.346	Nail house cover	1
35	03.04.05.690	Hex bolt M6*38	2	88			
36	03.04.05.257	Plain washer	1	89			
37				90	03.04.40.347	Nail tray ass'y	1
38				91			
39				92	03.04.22.035	Spring	1
40				93	03.04.40.348	Adjust holder	1
41				94	03.04.32.067	Spring holder	2
42				95	03.04.40.349	Nail house	1
43	03.04.40.351	O-ring 6*1.9	1	96	03.04.06.128	Adjust holder seal	1
44		Valve Sleeve	1	97	03.04.31.121	Nail house pin	1
45		O-ring 6.4*2	1	98	03.04.05.157-02	Hex bolt v6	2
46		O-ring 8.9*1.9	1	99	03.04.40.350	Nose cap	1
47		Trigger valve stem	1	100	03.04.29.188	Seal cap	1
48		Trigger valve stem	1	101	03.04.05.071	Hex bolt	1
49		O-ring 2.5*1.5	2	102		Air inlet plug	1
50		Trigger sleeve	1	103		Spring washer	1
51		Pin 2*1.5	2	104	03.04.05.265	Spring washer	4
52	03.04.02.131	Hook stop lever	1				

Note: If you need spare parts of this model, pls feel free to contact us or the distributor where you bought this tool. Tks!